

Citroen Xsara (combi), (rok prod. 1998-),

Zestaw śrubowy:

M12X70 2 szt.

M12X35 2 szt.

M10X35 8 szt.

Podkładki:

Fi12 4 szt.

Fi10X30 8 szt.

Sprzęzynówki:

Fi12 4 szt.

M12 4 szt.

Nakrętki:

M10 8 szt.



- Instrukcja montażu:
- Odkręcić koło zapasowe.
 - Zdjąć tłumik z tylnich uchwytów.
 - Belkę hak A przykroić przez technologiczne otwory 1 i 2 do tylnego pasa samochodu śrubami M10x35-8.8.
 - Przez otwory w boku elementu B przykroić element B do podłużnicy śrubami M10x35-8.8.
 - Przez otwór w elemencie B wykonać otwór \varnothing 10.5 w bocznej płaszczyźnie podłużnicy i skręcić śrubą M10x35-8.8 (punkt 4).
 - Element hak C przykroić do podłużnicy przez technologiczne otwory śrubami M10x35-8.8 w punktach 5.
 - Przez otwór w elemencie C (punkt 6) wykonać otwór w boku podłużnicy śrubami M12x70-8.8 (punkt 7).
 - Zamontować kulę oraz blachę pod gniazdko elektryczne za pomocą śrub M12x70-8.8, podkładki, podkładek sprężystych i nakrętek.
 - Dokręcić wszystkie śrub momentarni wg tabelki.
 - Podłączyć przewody elektryczne wg instrukcji fabrycznej samochodu.

Fitting instructions:

- Unscrew the spare wheel.
- Lower the damper from the rear hangers.
- Screw the main bar A to the rear belt of the car, through the technological holes (point 1 and 2), with bolts M10x35-8.8.
- Screw the element B to the metal clamp, through the holes in the side of the element B, with bolts M10x35-8.8 (point 3).
- Drill the hole \varnothing 10.5 in the side flat of the metal clamp, through the hole in the element B, and screw with bolt M10x35-8.8 (point 4).
- Screw the element C to the metal clamp, through the technological holes, with bolts M10x35-8.8 (point 5).
- Drill the hole \varnothing 10.5 in the side of the metal clamp, through the hole in the element C (point 6), and screw the element C to the metal clamp with bolt M10x35-8.8.
- Screw the element C to the main bar A with bolts M12x35-8.8 (point 7).
- Fix the tow ball and socket plate using 2 bolts M12x70-8.8, large washer and spring washers.
- Tighten all bolts according to the torque shown in the table.
- Connect electric wires according to the instruction of the car.

Moment skręcający dla śrub i nakrętek M8 25Nm; M10 55Nm; M12 85Nm; M14 135Nm ;M16 195Nm.